

Dwarf - Vliegschool Hilversum

completed

Ċ	Towbar	stowed
Je	Ship's papers	on board
Cessna 150 (PH-CQA) Check	Parking brake	set
A	Seats	asjust & secured
Ò	Safety belts	fastened
Ģ	Doors	closed & locked
F	Fuel selector	on
Ē	All electrical switches	off
50	Radios	off
-	Circuit breakers	in
na	Master switch	on
SS	Fuel guantity	checked
ě.	Starting Engine	
0	Carburetor heat	cold
	Mixture	rich
	Prime	max 1½ (throttle)
	Throttle	± 1 cm.
	Propeller area	clear
	Beacon light switch	on (if applicable)
	Ignition switch	start
	After Starting	
	Oil pressure	check
	Starter warning light	off
	Throttle	1,000 rpm
	Ammeter	check
	Flaps	up
	Radios	on
	Start flight time	notice
	During Taxiing	
	Brakes	check
	Gyros	check
	Engine Check	
	Parking brake	set
	Throttle	1,000 rpm
	Mixture	rich
	Carburetor heat	cold
	Check behind	clear
	Throttle	1,700 rpm
	Engine instruments	check
	Ammeter	check
	Suction	green
	Magnetos	max. drop 150 rpm max. diff. 75 rpm
	Carburetor heat	check operation
	Idling	500 - 700 rpm
	Throttle	1,000 rpm
	Throttle friction	cot

Throttle friction

set

Before Take-off	
Primer pump	closed & locked
Ignition	both
Flight controls	free & correct
Trim	set for take-off
Carburetor heat	cold
Mixture	rich
Flaps	as required
Flight instruments	check & set
Engine instruments	check
Radios & Nav. equipment	check & set
Safety belts	fastened
Doors & windows	closed & locked
Smoking	not allowed
Parking brake	off
Normal Take-off (see owne	1
Throttle	full
Lift nose at	50 kts
Climb	70 kts
After Take-off	
Brakes	apply
Flaps	up >200 ft
Throttle	full
Climb speed	± 70 kts
Cruise	
Cruise Throttle	± 2,300 rpm
Cruise Throttle Carburetor heat	
Cruise Throttle Carburetor heat Before Descent	± 2,300 rpm as required
Cruise Throttle Carburetor heat Before Descent Mixture	± 2,300 rpm as required rich
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat	± 2,300 rpm as required rich as required
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter	± 2,300 rpm as required rich as required set
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector	± 2,300 rpm as required rich as required
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks	± 2,300 rpm as required rich as required set on
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer	± 2,300 rpm as required rich as required set on closed & locked
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition	± 2,300 rpm as required rich as required set on closed & locked both
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat	± 2,300 rpm as required rich as required set on closed & locked both hot
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat	± 2,300 rpm as required rich as required set on closed & locked both hot
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle Mixture	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm rich
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle Mixture Flaps Fuel selector	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm rich 10°
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle Mixture Flaps Fuel selector Fuel selector Fuel quantity	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm rich 10° on
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle Mixture Flaps Fuel selector	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm rich 10° on checked
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle Mixture Flaps Fuel selector Fuel quantity Engine instruments	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm rich 10° on checked check
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle Mixture Flaps Fuel selector Fuel quantity Engine instruments Brakes Safety belts	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm rich 10° on checked check check
Cruise Throttle Carburetor heat Before Descent Mixture Carburetor heat Altimeter Fuel selector Downwind Checks Primer Ignition Carburetor heat Throttle Mixture Flaps Fuel selector Fuel quantity Engine instruments Brakes	± 2,300 rpm as required rich as required set on closed & locked both hot ± 2,000 rpm rich 10° on checked check check fastened

Dwarf - Vliegschool Hilversum

Throttle	± 1,500 rpm
Flaps	20°
Speed	± 70 kts
Final Checks	
Throttle	± 1,500 rpm
Flaps	20° - 40°
Speed	60 - 70 kts
After Landing	
Flaps	up
Pitot heat	off
Carburetor heat	cold
After Parking	
Parking brake	set
Throttle	1,000 rpm
Radios & Nav. equipment	off
All electric switches	off
Mixture	idle cut off
Ignition	off
Master switch	off
Control lock	install
Time & Tachometer	check

Go Around	
Throttle	full
Carburetor heat	cold
Flaps	20° at 65 kts 10° >200 ft flaps up
Fouch & Go	
Flaps	as required
Throttle	full
Carburetor heat	cold

Emergency Procedures

Engine Fire in Flight

Mixture	idle cut off
Fuel selector	off
Master switch	off
Cabin heat & air vents	off
	(except overhead)
Airspeed	120 kts

If fire is not extinguished, increase glide speed to find an airspeed which will provide an incombustible mixture.

Electrical Fire in Flight

	Master switch	off
	All electrical switches	off
	Radio switches	off
1	Cabin head & air vents	closed
ł	Fire extinguisher (if available)	active
2		

Fire breaks out & electrical power is necessary for continuance of flight

Master switch	on
Circuit breakers	check for faulty cir- cuit, do NOT reset
Radio & Electrical switches	on one by one to local- ize the short circuit
Cabin heat & air vents	open if fire is com- pletely extinguished

Refer also the Operations Manual for further details